

Maintenance of Concrete Floor Tiles

All stone tiles are porous, therefore it is important to seal the stone correctly to reduce the natural absorption and maintain the desired appearance and the surface will be easier to maintain.

Concrete is a durable natural surface, which has an industrial worn aesthetic, factory made blemishes, scuffs and scratches help the surface to wear well and hide any day to day damage. The following advice will help get the most from your Concrete flooring.

- Keep your floor clean and dust free with regular sweeping and vacuuming to remove all dirt. General household cleaners may be too aggressive and are likely to damage the sealants and finishes applied.
- Protect the floor from excessive dust and grit by installing mats next to external doors.
- Fit furniture with felt pads to protect from scratching and abrasion.
- Avoid marks from standing water by using protective mats under animal water bowls and around the base of plant pots.
- Avoid using decorators tape as the adhesives can react with the sealed surface causing damage once removed.
- Water and spillages should be removed quickly to avoid staining.
- For the purpose of cleaning sealed concrete surfaces use a mild detergent and rinse with warm water.